

MAINTENANCE OF ACRYLIC COLOR SURFACES

DAILY MAINTENANCE – Daily maintenance consists of removing standing water on the surface (where applicable). This should be done by means of a sponge roller designed for this purpose.

WEEKLY MAINTENANCE – Dirt, dust and debris should be removed from the surface by means of air blower. As dirt and dust are ground into the surface the texture of the color surface can wear excessively.

MONTHLY MAINTENANCE – Court surfaces should be washed once per month to remove ground in dirt. This may be accomplished by means of a water broom designed for this purpose. Alternative methods would be a hose nozzle or light duty pressure washer (care must be taken when using a pressure washer as it can strip the color off the surface).

ANNUAL MAINTENANCE – The court surface should be kept as dry as possible. Long term effects of standing water can cause delamination. Windscreens should be rolled up or removed during the winter months to reduce shaded areas on the color surface and promote melting. Use of ice picks, snow blowers, plows or snow shovels are not recommended and will void the warranty.

STAINS – Most stains on the surface can be removed by using a mild detergent. Wet the surface with water, sprinkle detergent (such as Tide[®]) on the surface and scrub with a broom (preferably a soft bristle). Rinse surface thoroughly with water immediately after scrubbing.

PATCHING – Surface chips or “racquet dings” can occur due to striking the surface with the tennis racquets. These are easily repaired by mixing a small amount of the court color with the same size silica sand that was originally used for texture. Mix to a putty-like consistency and fill the area level onto the court surface taking care not to leave any ridges using a putty knife or hand trowel. Allow patch to dry and then sand smooth if needed. Surface must be clean and dry prior to attempting repair.